


Connection/ Wiring Diagrams

Part Winding Start (Wye Only)

Speed: Single
Phase: 3
Voltage: Single
Winding: Y only
Special Feature: Part winding start

Note: Suitable for unit previously approved for part winding start (a standard Star - Y 230/460 9 lead motor may often be used for 230V part winding - a special winding is required for 460V part winding start)



[Home](#) [Email](#)

Copyright © 2000 U.S. Electrical Motors, All rights reserved