Contactors and Contactor Assemblies

Control Relays, Coupling Relays

3RH21 control relays, 4-pole

SIRIUS

3RH2122-1BB40

3RH2122-1BF40

3RH2122-1BM40

Selection and ordering data AC and DC operation





Rated current Auxiliary contacts

22E

2

2

24

110/120

220/240



3RH11 . . -2

Size S00 – Terminal designations according to EN 50011

For screw and snap-on mounti

	at 240 V NEMA A600/Q600	Ident- ification No.	Versio	n L	Rated control supply voltage <i>U</i> _S	AC Operation Screw Terminals ^{1) 2)}	Rated control supply voltage U_s	DC Operation Screw Terminals ^{1) 2}
	Amps		NO	NC	V AC 50/60 Hz ³⁾	Order No.	V DC	Order No.
ti	ng onto TH 3	5 standar	d mou	ınting ı	rail			
	10	40E	4		24 110/120 220/240	3RH2140-1AB00 3RH2140-1AK60 3RH2140-1AP60	24 110 220	3RH2140-1BB40 3RH2140-1BF40 3RH2140-1BM40
	10	31E	3	1	24 110/120 220/240	3RH2131-1AB00 3RH2131-1AK60 3RH2131-1AP60	24 110 220	3RH2131-1BB40 3RH2131-1BF40 3RH2131-1BM40

Notes

For further voltages, see page 2/49.
For accessories, see pages 2/66-2/77.
For technical data, see pages 2/185-2/188.
For overview, see page 2/116.
For position terminals, see page 2/202-2/203.
For dimension drawings, see page 2/124.

10

1)The 3RH21 contactor relays are also available with spring-type terminals. Replace the 8th digit of the order number with a "2" e.g. "3RH2140-2AB00"

3RH2122-1AB00

3RH2122-1AK60

3RH2122-1AP60

110

220

- 2)The 3RH21 contactor relays are also available with ring lug terminals. Replace the 8th digit of the order number with a "4" e.g. "3RH2140-4AB00"
- 3)AC coil operating range at 50 Hz: 0.8 to 1.1 x Us at 60 Hz: 0.85 to 1.1 x Us
- 4)For AC-15/AC-14 the following applies: $I_{e} = 6A$ for mounted auxiliary contacts.



Revised • 04/20/15

Accessories for 3RT contactors / 3RH control relays

Auxiliary switch blocks

Selection and ordering data













3RH2911-1FA40

Type

3RH2911-2FA40

3RH19 21-1C...

3RH19 21-2C . .

3RH19 21-1LA..


3RH19 21-1MA..

For contactors/	Rat
control relays	ope
	Cur
	6A

Rated
operationa
Current 3)
6A
NEMA
A600/Q600

Contactor with HS block Ident. No.

Connections	
position	



Screw Terminals ¹⁾
Order No.

Spring Terminals ¹⁾
Order No.

Auxiliary switch blocks for snapping onto the	front according to EN 50005

Auxiliary switch bio	cks for snappi	ng onto the from	it accordin	y to Ei	4 50005			
Sizes S00 to S2								
2- or 4-pole auxiliary s	witch blocks for	r assembling cont	actors					
with 3 and 5 or 4 and 6	auxiliary conta	cts						
3RT2. 1.,	40		4	_	_	_	3RH2911-1FA40	3RH2911-2FA40
3RT2. 2.,	22		2	2	_	_	3RH2911-1FA22	3RH2911-2FA22
3RT2. 3	04 1)		_	4	_	_	3RH2911-1FA04	3RH2911-2FA04
3RH21	11 ²⁾		_	_	1	1	3RH2911-1FB11	3RH2911-2FB11
3RH24	22 ²⁾		1	1	1	1	3RH2911-1FB22	3RH2911-2FB22
	22 ²⁾		_	_	2	2	3RH2911-1FC22	3RH2911-2FC22
1- and 2- pole auxiliar	y switch blocks,	cable entry from	above or be	low				
3RT2. 1.,	10	Тор	1	_	_	_	3RH2911-1AA10	_
3RT2. 2.,		Bottom	1	_	_	_	3RH2911-1BA10	_
3RT2. 3.,	01	Тор	_	1	_	_	3RH2911-1AA01	_
3RH21		Bottom	_	1	_	_	3RH2911-1BA01	_
3RH24	11	Тор	1	1	_	_	3RH2911-1LA11	_
		Bottom	1	1	_	_	3RH2911-1MA11	_
	20	Тор	2	_	_	_	3RH2911-1LA20	_
		Bottom	2	_	_	_	3RH2911-1MA20	_
Sizes S3 to S12								
4-pole auxiliary switch	n blocks							
3RT1. 4 to	40		4	_	_	_	3RH1921-1FA40	3RH1921-2FA40
3RT1. 7,	31		3	1	_	_	3RH1921-1FA31	3RH1921-2FA31
3RT11	22		2	2	_	_	3RH1921-1FA22	3RH1921-2FA22
	04		_	4	_	_	3RH1921-1FA04	3RH1921-2FA04
	22 U		_	_	2	2	3RH1921-1FC22	3RH1921-2FC22
Single-pole auxiliary s	witch blocks (al	so compliant with	EN 5001 ²⁾					
3RT1. 4 to	_		1	_	_	_	3RH1921-1CA10	3RH1921-2CA10
3RT1. 7,	_		_	1	_	_	3RH1921-1CA01	3RH1921-2CA01
3RT11	_		_	_	1	_	3RH1921-1CD10	_
	_		_	_	_	1	3RH1921-1CD01	_
2-pole auxiliary switch	n blocks with cal	ble entry from one	side					
3RT1. 4 to	_	Тор	1	1	_	_	3RH19 21-1LA11	_
3RT1. 7,	_	Bottom	1	1	_	_	3RH19 21-1MA11	_
3RT11	_	Тор	2	_	_	_	3RH19 21-1LA20	_
	_	Bottom	2	_	_	_	3RH19 21-1MA20	_
	_	Тор	_	2	_	_	3RH19 21-1LA02	_
	_	Bottom	_	2	_	_	3RH19 21-1MA02	_

EN50005 and EN50012 designate the markings of the auxiliary terminal numbers. For position of the terminals see pages 2/202-2/206. For int. circuit diagrams see page 2/190.

Mounting is permitted only on basic units which have no integrated NC contact.

²⁾ Version with early make and delayed break contacts

³⁾ UL ratings: See appendix page 19/7